



# **Hordein Microplate Assay Kit**

## **User Manual**

**Catalog # FTA0179**

(Version 1.2A)

Detection and Quantification of Hordein Content in Tissue extracts,  
Powder Samples.

**For research use only. Not for diagnostic or therapeutic procedures.**

|                                               |   |
|-----------------------------------------------|---|
| I. INTRODUCTION.....                          | 2 |
| II. KIT COMPONENTS.....                       | 3 |
| III. MATERIALS REQUIRED BUT NOT PROVIDED..... | 3 |
| IV. SAMPLE PREPARATION.....                   | 4 |
| V. ASSAY PROCEDURE.....                       | 5 |
| VI. CALCULATION.....                          | 6 |
| VII. TYPICAL DATA.....                        | 7 |
| VIII. TECHNICAL SUPPORT.....                  | 7 |
| IX. NOTES.....                                | 7 |

## I. INTRODUCTION

Hordein Microplate Assay Kit is a sensitive assay for determining Hordein content in plant samples. The color intensity, measured at 595 nm, is proportionate to Hordein content in the sample.

## II. KIT COMPONENTS

| Component          | Volume     | Storage |
|--------------------|------------|---------|
| 96-Well Microplate | 1 plate    |         |
| Assay Buffer I     | 30 ml x 2  | 4 °C    |
| Assay Buffer II    | 30 ml x 2  | 4 °C    |
| Assay Buffer III   | 30 ml x 2  | 4 °C    |
| Dye Reagent        | 20 ml x 1  | 4 °C    |
| Standard           | Powder x 1 | -20 °C  |
| Technical Manual   | 1 Manual   |         |

**Note:**

**Standard:** add 1 ml distilled water to dissolve before use, the concentration will be 0.2 mg/ml.

## III. MATERIALS REQUIRED BUT NOT PROVIDED

1. Microplate reader to read absorbance at 595 nm
2. Distilled water
3. Pipettor, multi-channel pipettor
4. Pipette tips
5. Mortar
6. Ice
7. Centrifuge
8. Timer
9. Lab rotator

#### IV. SAMPLE PREPARATION

##### 1. For tissue samples

Weigh out 0.05 g tissue, homogenize with 0.5 ml Assay Buffer I on ice, transfer it to centrifuge tube and mix on a lab rotator for 30 minutes; centrifuged at 10000g 4 °C for 10 minutes, discard the supernatant; then add 0.5 ml Assay Buffer II into the tube, mix on a lab rotator for 30 minutes; centrifuged at 10000g 4 °C for 10 minutes, discard the supernatant; then add 0.5 ml Assay Buffer III into the tube, mix on a lab rotator for 30 minutes, take the supernatant into a new centrifuge tube and keep it on ice for detection.

##### 2. For powder samples

Weigh out 0.05 g powder, add 0.5 ml Assay Buffer I to dissolve, mix on a lab rotator for 30 minutes; centrifuged at 10000g 4 °C for 10 minutes, discard the supernatant; then add 0.5 ml Assay Buffer II into the tube, mix on a lab rotator for 30 minutes; centrifuged at 10000g 4 °C for 10 minutes, discard the supernatant; then add 0.5 ml Assay Buffer III into the tube, mix on a lab rotator for 30 minutes, take the supernatant into a new centrifuge tube and keep it on ice for detection.

## V. ASSAY PROCEDURE

Add following reagents into the microplate:

| Reagent                                                                | Sample      | Standard    | Blank       |
|------------------------------------------------------------------------|-------------|-------------|-------------|
| Sample                                                                 | 10 $\mu$ l  | --          | --          |
| Standard                                                               | --          | 10 $\mu$ l  | --          |
| Distilled water                                                        | --          | --          | 10 $\mu$ l  |
| Dye Reagent                                                            | 200 $\mu$ l | 200 $\mu$ l | 200 $\mu$ l |
| Mix, wait for 2 minutes, measured at 595 nm and record the absorbance. |             |             |             |

**Note:**

- 1) Perform 2-fold serial dilutions of the top standards to make the standard curve.
- 2) The concentrations can vary over a wide range depending on the different samples.

For unknown samples, we recommend doing a pilot experiment & testing several doses to ensure the readings are within the standard curve range.

## VI. CALCULATION

1. According to the weight of sample

$$\begin{aligned}\text{Hordein (mg/g)} &= (C_{\text{Standard}} \times V_{\text{Standard}}) \times (\text{OD}_{\text{Sample}} - \text{OD}_{\text{Blank}}) / (\text{OD}_{\text{Standard}} - \text{OD}_{\text{Blank}}) / \\ &\quad (V_{\text{Sample}} \times W / V_{\text{Assay}}) \\ &= 4 \times (\text{OD}_{\text{Sample}} - \text{OD}_{\text{Blank}}) / (\text{OD}_{\text{Standard}} - \text{OD}_{\text{Blank}}) / W\end{aligned}$$

$C_{\text{Standard}}$ : the standard concentration, 2 mg/ml;

$V_{\text{Standard}}$ : the volume of standard, 10  $\mu\text{l}$  = 0.01 ml;


$V_{\text{Sample}}$ : the volume of sample, 10  $\mu\text{l}$  = 0.01 ml;

$W$ : the weight of sample, g;

$V_{\text{Assay}}$ : the volume of Assay Buffer III, 0.5 ml.

## VII. TYPICAL DATA

The standard curve is for demonstration only. A standard curve must be run with each assay.



Detection Range: 0.02 mg/ml - 2 mg/ml

## VIII. TECHNICAL SUPPORT

For troubleshooting, information or assistance, please go online to [www.cohesionbio.com](http://www.cohesionbio.com) or contact us at [techsupport@cohesionbio.com](mailto:techsupport@cohesionbio.com)

## IX. NOTES